

## TAITO SPACE CHASER

PARTS SIDE - G    SOLDER SIDE - G

GND - 1	A - GND
GND - 2	B - GND
GND - 3	C - SPEAKER - GND
+5V - 4	D - +5V
+12V - 5	E - +12V
KEY - 6	F - KEY
COIN - 7	H - TILT
NAME RESET - 8	J - POR
SPEAKER (+) - 9	K - 2P UP
1P START - 10	L - 2P START
1P ENERGY - 11	M - 2P ENERGY
1P RIGHT - 12	N - 2P RIGHT
1P DOWN - 13	P - 2P DOWN
1P LEFT - 14	R - 2P LEFT
1P UP - 15	S - COMP SYNC
RED - 16	T - GREEN
BLUE - 17	U -- COIN LOCKOUT
VIDEO GND - 18	V -- COIN LOCKOUT - GND

PARTS SIDE - T    SOLDER SIDE - T

+5V - 1	A - +5V
+5V - 2	B - +5V
+12V - 3	C - +12V
+12V - 4	D - +12V
-5V - 6	E - -5V
+15V - 6	F - +15V
KEY - 7	H - KEY
8	J
9	K
10	L
11	M
12	N
13	P
GND - 14	R - GND
GND - 15	S - GND
GND - 16	T - GND
GND - 17	U - GND
COMP VIDEO OUT - (B+W?) - 18	V